M.A.C. SOLUTIONS

PROCESSVUE

Enabling Active Directory on SOE

Abstract

Enabling Active Directory for SOE.

Important!

- For active directory to work, a group called 'ProcessVue Users' needs to be created on the domain.
- For domain users to be able to access ProcessVue, they need to have the 'ProcessVue Users' assigned to them.

Please note: There is no need to create a PVadmin user on the domain as the PVadmin account is validated on our database and not the domain.

To enable AD for SOE:

1. Lunch SOE application and login using the PVadmin credentials.
2. Go to Admin> User Manager
3. On the Active Directory tab
    a. Check 'Enable Active Directory'
    b. Type the domain name/IP address
    c. Click the test button
4. If the connection is successful, user groups will be retrieved and displayed as follows:





5. Click the 'Apply' button, confirm the changed will take you to the login page in which you will be able to see that active directory is now enabled